

# Door Hole Template

1. Fold Template on dashed line. Use scissors to cut around the solid line of the Template & remove outer strip of paper.
2. Determine desired location of hole-opening on bottom of door.
3. Position Template so that the folded dashed line aligns with bottom of door.
4. Carefully trace hole outline on door.
5. Darken hole outline on door so that it can be easily seen when sawing.
6. Before sawing - double-check to ensure that you traced correctly by placing one of the CATHOLE frames over the traced hole outline. (frame should cover hole outline).
7. Carefully saw around hole outline.  
Note: You may want to cover the saw base with masking tape to avoid scratching the door surface.

**CH ENTERPRISE**

US PATENT  
5,458,088

[www.cathole.com](http://www.cathole.com)

Is your CATHOLE a "5 STAR" product?

YES .. Please rate it on your retailer's website

NO .. Please let us know ([cathole@ameritech.net](mailto:cathole@ameritech.net))

